



How to clean the magstripe reader




The magstripe reader

The magstripe reader is equipped with a magnetic head to read out magstripe cards. Because of direct contact between the head and the card, the head is exposed to dirt, grease and other substances from the user card.

The dirt accumulates causing the head to perform less effectively in time. To resolve this, the card reader needs to be cleaned.

Cleaning the magstripe reader

To clean the magstripe reader, please swipe the cleaning card through the slide. Check the card for dirt, flip the card and repeat the process until the head is clean. We advise to clean the magstripe reader every 1000 cards.

 :The head is clean when the card no longer absorbs any substances from the magstripe head.



Please use the Inepro SCD Cleaning Cards (12 pack) - P255552, to clean the magstripe reader.